2.4 GHz Cordless Telephone
with Caller ID/Call Waiting

43-3537

Step 4 in “Editing the Speed Dial Number” on Page 33 of your Owner’s Manual is incorrect. This step should read as follows:

4. To edit the number, repeatedly press **DEL/CH** to erase up to the incorrect entry, enter the correct number, then press **SEL**.

ADDENDUM

© 2002 RadioShack Corporation.
All Rights Reserved.
RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

43-3537
UCZZ01370ZZ
04A02
Printed in China

RadioShack Corporation
Fort Worth, Texas 76102